

5/7/21

PRACTICAL - 4

AIM:

Setup and configure a LAN using a switch & Ethernet cables in your lab.

What is a LAN?

A local area network (LAN) refers to a network that connects devices within a limited area. Such as an office building, school or home. It enables users to share resources, including data, printers & internet access. LAN connects devices to promote collaboration & transfers information between users, such as computers, printers, servers and switches. A local area network (LAN) switch serves as the primary connecting device, managing and directing communication within the local network.

Each connected device on a LAN switch can communicate directly with each other's allowing the task & secure data transfer.

How to set up a LAN

Step 1: Plan and Design an appropriate network topology taking into account network requirements & equipment location.

Step 2: You can take 4 computers, a switch with 8, 16 or 24 ports which is sufficient for networks of these size & 4 Ethernet cables.

Step 3: Connect your computer to network switch via an ethernet cable, which is as simple as plugging one end of ethernet cable into your computer & other end into your network switch.

Step 4: Assign IP Address to your PC's

1. Log on to the client computer as Administrator or as user.
2. Click Network and Internet connections.
3. Right click Local Area connection / Ethernet → Go to properties → select use of the following IP address option and assign IP address.

Similarly assign IP address to all the PC's connected to switch

PC₁ - IP address : 10.1.1.1, Subnet mask 255.0.0.0

PC₂ - IP address : 10.1.1.2, Subnet mask 255.0.0.0

PC₃ - IP address : 10.1.1.3, Subnet mask 255.0.0.0

PC₄ - IP address : 10.1.1.4, Subnet mask 255.0.0.0

Step 5:

Configure a network switch

1. Connect your computer to the switch. To access the switch using an ethernet cable.

2. Log in to the web interface: Open a web browser & enter the IP address of the switch in the address bar. This should bring up the login page for the switch's web interface.

3. Configure Basic settings: Once you're logged in you will be able to configure basic settings for the switch.


4. Assign IP address the connectivity as 10.1.1.5, subnet mask 255.0.0.0

Step 6: Check the connectivity b/w switch and other machine by using

Step 7: Select a folder → go to properties → Click sharing → share it with everyone on the source LAN.

Step 8: Try to access the shared folder from other computers of the network.

Student observation



Result

Thus we setup and configure an LAN using a switch & Ethernet cables in our Lab